

ThermaCheck Plus Thermometer

in a robust IP66/67 waterproof case

- backlight, auto-off, max/min & hold functions
- integrated rubber seal for durability
- minimum 5 years battery life
- 2 year guarantee

The ThermaCheck Plus is a waterproof, hand held thermistor thermometer which offers IP66/67 protection and is housed in a robust waterproof white ABS case. The thermometer utilises state of the art electronic circuitry, designed for reliability and ease of use and can be submerged or washed under a running tap - ideal for food processing applications where cleaning is paramount.

Measuring temperature over the range of -39.9 to 149.9 °C with a 0.1 °C resolution, the ThermaCheck Plus features a large, easy to read, LCD display with max/min, °C/°F, hold, open circuit, low battery indication and an optional backlight. The unit also incorporates an auto-power off facility that automatically turns the instrument off after ten minutes, maximising battery life.

The instrument is housed in an ergonomic, ABS case that includes 'Biomaster' additive which reduces bacterial growth. Each unit has an integrated rubber seal to ensure complete water resistance and help reduce the possibility of damage in harsh environments.

The ThermaCheck Plus is supplied complete with a permanently attached food penetration probe with a 130 mm stainless steel stem and one metre coiled PU lead.



optional accessories

- protective silicone boot, wide range of colours available - see below for details
- anti-bacterial wipes - see page 33



| specification | ThermaCheck Plus |
|---|-------------------------------|
| range | -39.9 to 149.9 °C |
| resolution | 0.1 °C |
| system accuracy | ±0.4 °C (-10 to 70 °C) |
| battery | 3 x 1.5 volt AAA |
| battery life | minimum 5 years (10000 hours) |
| sensor type | thermistor |
| display | 15 mm LCD |
| dimensions | 32 x 71 x 141 mm |
| weight | 298 grams |
| <i>FREE traceable certificate of calibration included</i> | |

