

CATERTEMP® THERMOMETER & PROBE

- High system accuracy $\pm 0.4\text{ }^{\circ}\text{C}$ & $0.1\text{ }^{\circ}\text{C}$ resolution
- FREE traceable certificate of calibration

The CaterTemp professional digital thermometer is designed with the catering and food processing industry in mind and incorporates a combination of proven circuitry and durability.

Each unit is housed in a robust ABS case that includes Biomaster Antimicrobial Technology which reduces bacterial growth such as MRSA and E.coli.

The instrument features a bright, easy to read LCD, displaying open circuit and low battery indication, when applicable. Each CaterTemp is supplied with a permanently attached food penetration probe with a 130 mm pointed, stainless steel stem and one metre coiled PU lead.



Specification	CaterTemp
Range	-49.9 to 299.9 °C
Resolution	0.1 °C
Accuracy	$\pm 0.4\text{ }^{\circ}\text{C}$ (-49.9 to 149.9 °C) otherwise $\pm 1\%$
Battery & life	3 x 1.5 volt AAA - 10000 hours
Sensor type	K thermocouple
Display	12 mm LCD
Dimensions	25 x 56 x 128 mm
Weight	175 grams
FREE traceable certificate of calibration included	

Description
CaterTemp
Protective silicone boot - black*
S/steel wall bracket & boot
*

CATERING

CATERTEMP® METAL THERMOMETER

- Extruded aluminium case for superior durability
- Waterproof to IP67

The CaterTemp Metal thermometer is housed in a robust extruded aluminium waterproof case, offering IP67 protection, with a white coated finish containing Biomaster Antimicrobial Technology. Designed for reliability and ease of use in day-to-day catering and food processing applications.

The CaterTemp Metal thermometer measures temperature over the range of $-49.9\text{ }^{\circ}\text{C}$ to $299.9\text{ }^{\circ}\text{C}$ and features a large, easy to read, LCD display.

Each unit is supplied with a permanently attached, water resistant, heavy duty, food penetration probe with a $\text{Ø}3.3 \times 130\text{ mm}$ stainless steel stem and one metre PU coiled lead. The probe is both strong, versatile and suitable for a variety of applications including liquids, semi-solids and granular materials.



Specification	CaterTemp Metal
Range	$-49.9\text{ }^{\circ}\text{C}$ to $299.9\text{ }^{\circ}\text{C}$
Resolution	0.1 °C
Accuracy	$\pm 0.4\text{ }^{\circ}\text{C}$ (-49.9 to 149.9 °C) or otherwise $\pm 1\%$
Battery & life	3 x AAA - 10,000 hours @ 25°C
Sensor type	K thermocouple
Display	12 mm LCD
Dimensions	37 x 61.4 x 177 mm
Weight	325 grams
FREE traceable certificate of calibration included	

Order code	Description
	CaterTemp Metal
	Stainless steel wall bracket